




Model: AE-AB00-40X

- Insertion Loss




- Return Loss




Model: AE-AB00-40X

- Attenuation Range



- Phase Shift



Model: AE-AB00-40X

-Attenuation Flatness-

