




Model: AT-6000-60X

- Insertion Loss




- Return Loss




Model: AT-6000-60X

- Attenuation
(0 – 60 dB)




- Attenuation
(10 dB)




Model: AT-6000-60X

- Attenuation
(20 dB)




- Attenuation
(30 dB)




Model: AT-6000-60X

- Attenuation
(40 dB)




- Attenuation
(50 dB)



Model: AT-6000-60X

- Attenuation (60 dB)



- Phase Variation

