




Model: BT-S000-HS

-Insertion Loss



-Return Loss



Model: BT-S000-HS

- Out-Band Response
(Insertion Loss
/ Return Loss)

