



Model: BC-003A-20S

-Insertion Loss
(Input / Output)




-Coupling
(Cpl-In & Cpl-Out)



Model: BC-003A-20S

-Return Loss



- Isolation (Cpl-In & Cpl-Out)

