



Model: BC-0060-10X

-Insertion Loss  
(Input / Output)



-Return Loss  
(Input / Output)

-Coupling



-Return Loss  
(Coupling)



Model: BC-0060-10X

-Directivity

