



Model: BC-050S-20S

- Insertion Loss
(Input / Output)





- Coupling
(Cpl-In & Cpl-Out)



Model: BC-050S-20S

- Return Loss



- Directivity

