




Model: PS-1000-6X

-Insertion Loss




-Return Loss



Model: PS-1000-6X

-Isolation



-Phase Error

