




Model: PS-3000-8X

-Insertion Loss




-Return Loss



Model: PS-3000-8X

-Isolation



-Phase Error

